
Field & Flame

Tower Heater

SAFETY INSTRUCTIONS



IMPORTANT

This manual contains important safety information concerning the maintenance, use and operation of this product. Failure to follow the instructions contained in this manual may result in serious injury. Do not operate this product unless you have read and understood the contents of this manual.

- For outdoor use only.
- To avoid possible electric shocks, do **NOT** place the cable, plug or heater in water or in any other liquid.
- If the power cable is damaged, it must be replaced by the manufacturer, its service technician or by someone else authorised by the manufacturer. In the event of handling of appliances by non-authorised people, the guarantee will immediately cease to be valid.
- Do **NOT** use the heater if it is damaged.
- To disconnect the heater, wait until it has been switched off and then unplug the cable from the electrical socket.
- Do **NOT** leave the heater unattended whilst it is on. Ensure that the heater has come to a complete stop before dismantling appliances. Unplug appliance after each use.
- Do **NOT** allow children to operate the heater. Do **NOT** leave the heater unattended when children are nearby.
- Children of less than 3 years should be kept away unless continuously supervised.
- Children aged from 3 years and less than 8 years shall not plug in, regulate or clean the appliance or perform user maintenance.
- Do **NOT** touch or move the heater during use.
- Do **NOT** dispose of this product as unclassified municipal rubbish. Due to the use of electrical parts, this product must be collected separately.
- **CAUTION** - Some parts of this product can become very hot and cause burns.
- **WARNING** - The heater shall, under no circumstances, be covered with insulating material or similar material.
- The heater must not be located immediately below an electrical socket.
- The power supplied to this unit must comply with the electrical requirements on the label. If the incorrect power is used, this may result in damage to the product or a fire.


- Do **NOT** use the heater near flammable objects, gas, or dust.
- In order to avoid injury, do **NOT** touch the heater during operation.
- Do **NOT** place any objects on the surface of the heater during operation.
- Do **NOT** use the heater with automatic electrified sequencers, timers or any other devices.
- If the heater does not operate correctly, contact the point of sale. Do not try to repair the heater by yourself.
- Keep these instructions for future reference.

PARTS IDENTIFICATION

Parts	Description	Quantity
A	Heater	1
B	Base	2
C	Screw	3
D	Allen/Hex Key	1


ASSEMBLY

1. Place the 2 base parts (B) together to create a circular base.




2. Using the Allen/Hex Key (D), take the 3 screws (C) and attach the base to the bottom of the heater (A) as shown in the diagram.

OPERATION



- OFF** Power off
- LOW** Medium heat (750W)
- HIGH** High heat (1500W)



CLEANING & CARE



CAUTION

Risk of injury! Allow the heater to cool completely before inspecting it for damage or cleaning it.

- Always turn off and unplug the heater before cleaning or performing maintenance.
- To clean the heater, use a damp cloth and make sure to dry any excess water once cleaned.
- **ATTENTION** - Do **NOT** place the heater in or around water.

TROUBLESHOOTING

- If the heater does not emit any heat after switching it on, check that the heater is plugged into the electrical socket properly.
- After the first use, it is normal for the heater to emit a small amount of smoke and strange smell. This will disappear with continued use.

SPECIFICATION

Model	THL021P
Voltage	220-240V ~50Hz
Power	1500W (MAX.)
Weight	7.6kg

CONFORMITY WITH DIRECTIVES

Conforms with relevant European Directives



ENVIRONMENTAL PROTECTION

For electrical products sold within the European Community.

This appliance is labeled in accordance with European Directive 2002/96/EC concerning Waste Electrical and Electronic Equipment (WEEE). Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

GUARANTEE


For your convenience, you are not required to complete a form and return it to us in order to validate your guarantee. However, please ensure that you retain your receipt which will act as both proof of purchase and a guarantee validation document. **We recommend that you attach your receipt to this documentation.**

Your product carries a 12 month guarantee from the date of original purchase (or as otherwise provided in writing at point of purchase). If your product fails to operate to its specification, due to faulty workmanship or materials during the guarantee period, we will either repair or replace the product. We will use our discretion to determine whether to offer a repair or provide a replacement. The product will not be covered by the guarantee if it has been misused, transformed, modified or altered in any way.

If your product fails within the guarantee period please ensure that you have all necessary documentation available including proof of purchase (receipt or invoice with serial number, location and date of purchase) in addition to all original undamaged packaging and leaflets etc. It is strongly recommended that you inspect your product carefully before it is used or installed. For full details of your product you should refer to the instruction manual which accompanies the product. You are strongly advised to read this manual carefully in its entirety and to retain it for future reference.

This product guarantee does not affect your statutory rights.

CUSTOMER HELPLINE

 +44 (0) 3300 882 069

 customer.support@firedupcorporation.com



www.firedupcorporation.com

Fired Up Corporation Ltd
Fired Up Buildings
HD1 3LF, UK

Fired Up Corporation
(Ireland) Ltd
71, D02 P593, Dublin